












©2007 Research In Motion Limited. All Rights Reserved. The BlackBerry and RIM families of related marks, images, and symbols are the exclusive properties of Research In Motion Limited. RIM, Research In Motion, BlackBerry, "Always On, Always Connected" and the "envelope in motion" symbol are registered with the U.S. Patent and Trademark Office and may be pending or registered in other countries. All other brands, product names, company names, trademarks, and service marks are the properties of their respective

MAT-17276-001 | PRINTSPEC-020 | SWD-318176-1123093230-001 | RBQ41CW

owners.



# **Start me up**

Thank you for choosing a BlackBerry® Pearl™ smartphone! See the *Getting Started Guide* that came with your device for step-by-step instructions for your device.

# **Setup checklist**

Complete the following tasks to set up your device. See the *Getting Started Guide* that came with your BlackBerry® device for help.

- Insert the SIM card
- Insert the battery
- Charge the battery
- Complete the setup wizard

# **Keys and features**



### **Typing tips**

- To capitalize a letter, hold the letter key until the capitalized letter appears or press the key and the letter key.
- To type the alternate character on a key, press the key and the character key. For example, to type a question mark (?), press the key and ...
- To type a symbol, press the key. To view more symbols, press the key again. Type the letter that appears below the symbol.
- To type an accented or special character, hold the letter key and roll the trackball to the left or right. Click a character. For example, to type ü, hold and roll the trackball to the left until ü is highlighted. Click the trackball.
- To turn on NUM lock, hold the key and press the key. To turn off NUM lock, press the key.

# **Save time**

See the *Getting Started Guide* that came with your BlackBerry® device or click **Help** on your device for more information about using your device.

# Home screen tips

- To open the application list, press the key.
- To return to the Home screen, press the key.
- To lock the keyboard, on the Home screen, hold the keyboard, press the key and the key.
- To lock the device, set a password. On the Home screen, hold the key. To unlock the device, type your password. Press the key.
- To switch between the Default and Vibrate notification profiles, on the Home screen, hold the key.

## Phone tips

- To make a call from the Home screen, type the phone number. Press the key.
- To end a call, press the key.
- To answer a call, press the key.
- To turn on or turn off mute during a call, press the Mute key.
- To turn on or turn off the speakerphone during a call, press the key.
- To adjust the volume during a call, press the **Volume** keys.
- To call a highlighted contact or phone number, press the key.

#### Try this

Make a call using a voice command.

- 1. In the address book, press the key.
- Click New Address.
- 3. Type the contact information.
- 4. Click the trackball.
- Click Save.
- 6. In the voice dialing application, wait for the sound.
- 7. Say "Call" and a contact name or phone number.

To end the call, press the key.

### Message tips

- To move up a message, press  $( \vec{r} \cdot \vec{r} )$ .
- To move down a message, press
- To move to the top of a message list, press  $\begin{bmatrix} \mathbf{1} & \mathbf{\omega} \\ \mathbf{E} & \mathbf{R} \end{bmatrix}$
- To move to the bottom of a message list, press .
- To highlight adjacent messages, hold the key and roll the trackball.
- To compose a message from a message list, press the key.
- To reply to a message, press the key.
- To reply to all, press the key.
- To forward a message, press the key.

#### Try this

Copy text in a message and paste it into another application.

- 1. In a message, place the cursor before the text that you want to copy.
- 2. Press the key and roll the trackball.
- Click the trackball.
- 4. Click Copy.
- 5. Place the cursor where you want to paste the text.
- 6. Click the trackball.
- 7. Click Paste.

## **Browser tips**

- To follow a link, click the link.
- To move to a specific web page, press the key.
- To insert a period (.) in the web address field, press the key.
- To insert a slash mark (/) in the web address field, press the key and the key.
- To hide the banner, press the key. To view the banner, press the key.
- To add a bookmark, press the key.
- To open the bookmark list, press
- To stop loading a web page, press the > key.
- To close the browser, hold the key.

#### Try this

Move through a web page line by line.

- 1. On a web page, press the key.
- 2. Click Select Mode.

To select only links and fields as you move through a web page, press the key. Click **View Mode**.

## Organizer tips

- To move to the next day, week, or month in the calendar, press the key.
- To move to the previous day, week, or month in the calendar, press the key and the key.
- To convert a measurement in the calculator, type a number. Click the trackball. Click **To Metric** or **From Metric**. Click a conversion type.
- To change the status of a task in the task list, highlight a task. Press the key.
- To search for a contact in a list of contacts, type the contact name or initials separated by a space.

#### Try this

Assign a ring tone to a contact.

- In the address book, highlight a contact.
- 2. Press the 🗱 key.
- 3. Click Edit.
- 4. Click the trackball.
- 5. Click Add Custom Phone Tune
- 6. Set a ring tone.
- 7. Press the 🗱 key.
- 8. Click Save.

### Media tips

- To zoom in to a picture, press .
- To zoom out from a picture, press
- To zoom to the original picture size, press
- To rotate a picture, press the key.
- To pause a slide show, press the key.
- To resume a slide show, press the key.
- To pause a video or song, press the **Mute** key.
- To resume playing a video or song, press the **Mute** key.

### Try this

Take a picture.

- 1. In the camera, click the trackball.
- 2. Perform one of the following actions:
  - To take another picture, click the camera icon.
  - To delete the picture, click the **trash can** icon.
  - To set the picture as a caller ID picture or Home screen background, click the crop icon.
  - To forward the picture, click the envelope icon.
  - To rename and save the picture, click the **folder** icon.